

Montage Torque Control

1. Den Shroud abschrauben.
2. Torque Control über unterste Strebe schieben.
3. Shroud wieder anschrauben.
4. Wenn man von hinten auf den Propeller sieht sollte die dünne Kante des Torque Control leicht nach rechts zeigen. Zur Fixierung die 2 Madenschrauben anziehen.
5. Die Stärke des Torque Control läßt sich nach den persönlichen Wünschen des Tauchers einstellen.
6. Als Grundeinstellung schlagen wir einen Abstand von 2 cm von der äußersten linken Kante des Torque Control Bauteils bis zur Spitze vor.

Skizze:



Assembling the Torque Control

1. Remove the Carbon Shroud by removing the 4 screws.
(Don't loosen the 4 cross members !)
2. Push the Torque Control over the cross member next to the Zink anode
3. Fix the Carbon shroud again with the 4 screws
4. Look from the back side of the scooter at the propeller and Torque Control.
The Torque Control should show to the right side. (see drawing)
5. Now fix the 2 set screws to fix the torque control
6. You can adjust the force the Torque Control works by changing the angle of it.
7. The standard adjustment is about 2 cm .

